







Bolt/flangemøtrik

Only one bolt model is required for mounting your X-Tray system.



One M8 carriage bolt with a square shoulder to save you having to hold against when you tighten the nut. The bags are stand-up and re-closable.

Modeller

ARTIKLER / BESKRIVELSE		OVERFLADEBEHANDLING
	2761 X61 Bolt M8x27	Sort Zink
	2762 X62 Flange Nut M8	Sort Zink
	7100-031 Expander Bolt M8x65	Forzinket
	7100-070 Self drilling screw, washer head 4.2x19	Forzinket